Experiments-1 Name: Verification of Ohm's Law

Objectives:

- Find the resistance of a resistor from its colour code.
- Measure voltage, current and resistance values using a digital multimeter.
- Verify the validity of Ohm's Law.
- Test the voltage divider rule in a series circuit.

Apparatus:


- Breadboard
- Resistors $(3.3k \Omega, 5.6k \Omega)$
- Digital Multimeter (DMM)
- Digital Power Supply
- Wires

PRECAUTION

To avoid damage to the DMM:

- Keep it switched off while not in use.
- Before connecting the DMM, the measurement mode must be selected, and its meter range should be placed to its highest value.
- The red probe must connect to the correct terminal.

Circuit Diagram:



Data Table:

Table 1:						
Resistance	using colour co	ding				1000
		-			K-A	STATE OF THE
and 1	Band 2	Band 3	Band 4	Resistance ±	Resistance	
range (3)	Orange (3)	Red (2)	Gold (±5%)	tol ka	using DMM	% Error
(5)	Blue (6)		- '	3.135 - 3.465	3.24	1.82
	1.10(8)	Red (2)	Gold (±54.)	5.32-5.89	5.49	1.96

Table 2:

	Experime	ntal readin	igs	
3.3 KΩ Voltage	Current,	Voltage, I R	Power, I ² R	
2195	0.62	2.046	6-752	1.269
44.01	1:24	4.092	13:504	5.074
66.02	1.85	6.105	20:147	11.224
8 7.95	2.48	8.184	27:007	20.296
10 10.00	3.10	10.2/3	33.759	31.213

Table 3

- (1/0	Experime	ntal readin	gs
5.6 KΩ Voltage	Current,	Voltage, I R	Power, I ² R
2 1.97	6.36	2.016	0.726
4 4'02	0.72	4.032	2.963
65-94	1.69	6.104	6.653
8 7.96	1.46	8.127	11.936
10 10.02	1.82	10.192	18.549

Graph:

Attached.

Result Analysis:

From this experiment, we learn about the colour code of resistors. And it's matching with the assigned resistance of this resistor.

From the graph, we found a straight line, and it's continuously increasing. That means the larger the voltage applied, the bigger the current becomes. Ohm's Law also declares that. In short, our experiment completely follows Ohm's Law.

Questions and Answers:

01. Ohm's Law: Ohm's law states that electrical current in a resistive circuit is directly proportional to the applied voltage and inversely proportional to its resistance, provided all physical conditions and temperatures remain constant.

$$I = \frac{V}{R}$$
 in amperes (A)

Where V is the applied voltage in volts (V).

R is the resistance in ohms (Ω) .

I is the current in amperes (A).

The larger the applied voltage is, the larger the current becomes. The larger the resistance is, the smaller the current becomes.

- 02. Graph Attached
- **03.** Yes, our experiment circuit follows ohm's law. According to Ohm's Law, The larger the applied voltage, the larger the current. From the graph V vs I, we found an increasing straight line. Whenever we increase the voltage in our circuit, the current also increases. From the graph, we can say our experiment completely follows Ohm's Law.

04. ..

Probables botols writt night From the graph of R1

point-1:
$$(4.5, 1.4)$$

point-2: $(5.45, 1.7)$

Slope, $m_1 = \frac{6}{5.45-45}$

inverse of Slope,

$$m_1' = R_1 = \frac{19}{6} = 3.17 k.2$$

E-E JAA +E JAA.

From PMM,

$$R_{1} = 3.24 \times 10000$$

$$= \frac{3.24 - 3.77}{3.24} \times 10000$$

$$= 2.16 = 0.000$$

From the graph of R2

$$-1$$
 Slope, $m_1 = \frac{1-6.6}{5.46-3.3} = \frac{5}{27}$

inverse of slope,

$$m_2^{-1} = R_1 = \frac{27}{5} = 5.4 \text{ k.}2$$

From DMM,

 $R_2 = 5.49 \text{ k.}2$

These errore

These errore

This error happens because we draw the graph according to the best feed line.

Discussion:

In this experiment, we don't face any difficulties. We need to take care of the red jack when measuring the current. First, one of our group mates experimented alone then each member practiced it under his observation. From this experiment, we learn how to measure the voltage and current and use DMM and Digital Power Supply.

Attachment:

- 1. Graph of V vs I.
- 2. Simulation using Multisim.
- 3. Signed Data Table

Experiments-2 Name: KVL and Voltage Divider Rule using Series Circuit.


Objectives:

- Learn how to connect a series circuit on a breadboard.
- Validate the voltage divider rules.
- Verify Kirchhoff's voltage law.

Apparatus:


- Bread board
- Resistors (3.3k Ω , 4.7k Ω , 5.6k Ω)
- DC Power Supply
- Digital Multimeter (DMM)
- Connecting Wires

Circuit Diagram:



Data Table:

Resistance us	ing colour cod	ing			(KI)	illo and
Band 1	Band 2	Band 3	Band 4	Resistance ± tol kA	Resistance using DMM	% Error
On ange (3)	0 Karye (3)	Red (2)	Gold (±540)	3.135-3.465	3.24 KM	1.82
Yellow (4)	Violet (7)	Red (2)	Gold (25%)	4.465 - 4.935	464 42	1.58
Green (5)	Blue (6)	Red (2)	Gold (#5-1.)	2.32 - 2.88	551 KA	1. 61



de la companya de la	Req	The Control of the Co
0.5 6%	0.151.	30

Graph:

N/A

Result Analysis:

% Error

According to Kirchhoff's voltage law, in a circuit loop, voltage rise, and drops are equal. The data table-3 shows that the voltage rise was 15.10 V, and the voltage drop was 15.05 V. So, the voltage drop was approximately equal to the rise. Data table-4 also showed that it follows the voltage divider rule. In short, we can say that our experiment follows Kirchhoff's voltage law.

Questions and Answers:

01. Voltage division rule:

the voltage across a resistor in a series circuit is equal to the value of that resistor times the total applied voltage divided by the total resistance of the series configuration.

$$V_x = R_x \frac{E}{R_T}$$

02. Kirchhoff's voltage law (KVL).

the algebraic sum of the potential rises and drops around a closed path (or closed loop) is zero.

In symbolic form it can be written as

$$\Sigma_{\mathbb{C}}V = 0$$
 (Kirchhoff's voltage law in symbolic form) (

03. ...

3

Calculation of theoretical values:

$$\sqrt{R^3} = \frac{2.51}{13.39} \times 12.10$$

Frinon Calculation:

$$\sqrt{R_1} = \left| \frac{3.65 - 3.63}{3.65} \right| \times 1004.$$

$$\sqrt{R_2} = \left| \frac{5.23 - 5.22}{5.23} \right| \times 1004.$$

$$\sqrt{R_3} = \left| \frac{6.21 - 6.20}{6.21} \right| \times 1004.$$

$$= 0.164.$$

Here, Potential ruise, $V_s = 15.10 \,\text{V}$ Potential drops, $V_T = (3.63 + 5.22 + 6.20)$ $= 15.05 \,\text{V}$

Here, potential drops is approximately equal to the voltage rise. So, we can say that, our circuit follows KVL.

4 Calculation of theoretical values of Vab! Vas = 4.64+5.51 × 15.10 enperimenta value or Vab: 11.42V FRETOR = 11.45 | ×100% = 0.26 %. Here, theoretical value and experimental value appronimately equal. So, we can say that. at the point a-b our cineuit follows voltage dividen nules.

Discussion:

In this experiment, we learn how to make a series circuit using some resistors in a breadboard. Also, we verify Kirchhoff's voltage law and voltage divider rules. While we measured the voltage of R1, we faced some problems; DMM not giving us any stable output. It was slowly increasing. Then Lab Instructor helped us and taught about how to hold the jack of DMM. Then we get a stable result. Then we complete the rest of the experiment together, and we learn a lot.

Attachment:

- 01. Simulation using Multisim.
- 02. Signed Data Table

